





ARETE 2 ASL

ALL-SEASON LIGHT TENT



CHECK INSIDE THE TENT BAG FOR

- Tent body and rainfly
- Pole bag and stake bag
- 3 poles
- 4 guylines with tighteners
- 8 stakes



SETUP INSTRUCTIONS

1. Lay out tent. (If it's windy out, stake down floor.)
2. Grab either pole's black end and insert it into a pole sleeve by an orange front-corner tab; push gently until tip reaches the sleeve dead-end at the opposite corner.
3. Repeat with the other pole; set both exposed pole tips into front corner tabs' outer grommets.
4. Slide silver pole through sleeve above the door. Set both tips into a grommet in black tabs outside each end of the pole sleeve.
5. If you didn't do so yet, stake the tent down for greater stability.
6. Drape rainfly over tent so that orange tabs on fly and tent align.
7. On the underside of fly, attach the hook-and-loop tabs to the pole sleeves.
8. Buckle rainfly to tent at all corners. Tighten all buckles.
9. Stake vestibule loops down and pull cord through cleat until taut; then wedge cord into the cleat's slot to "lock" in place (Fig. 2).
10. Tension fly by tightening buckles and/or vestibule cleats.

TIPS:

Using extra guylines in wind: Tie free end of guylines to a guyout point on the fly. Pull a loop of line out from the tightener. Stake down the loop and slide tightener toward fly (Fig. 3). Additional stakes sold separately.

To speed setup next time, leave rainfly attached to tent during take-down (unless it's wet).

Increase ventilation by unzipping vents on rainfly and on tent ceiling.

Note: Pole included in the fly can be removed to give the tent smaller packed size.




FIG. 1
POLE ASSEMBLY




FIG. 2
LOCKING LINE IN CLEAT




FIG. 3
TIGHTENING GUYLINE

TO PROTECT YOUR TENT FLOOR, GET AN ARETE 2 ASL FOOTPRINT.

3 WAYS TO GET REPLACEMENT PARTS:
REI STORES • REI.COM • 1-800-426-4840



100% SATISFACTION GUARANTEED

PFD1011 107