

Adjust the length of a trekking pole with an external Power Lock II adjustment system



1. Open the tab to loosen the Power Lock closest to pole tip
2. Set the desired length
3. Close the tab to tighten the Power Lock mechanism
4. Repeat steps 1 – 3 for with the second Power Lock on 3-section trekking poles

NOTE: For optimal stability, make sure that the length markings are the same on all pole sections.